

CODE	Artikel	Deutsch	Englisch	QTY
1	YY801800	Elektromotor (1800 Watt)	electric motor	1
2	4540410010	Motorabdeckung	motor shield	1
3	0106005013	Schraube	cross slot ST screw	5
4	4540409010	Spindelhülle	spindle sheath	1
5	4540408010	Motorhalterung	motor connector	1
6	4540414010	Clip	wire clip	1
7	DY25UF/450V	Kondensator	capacitor	1
8	4540413010	Buchse	spacer	4
9	4540411010/02	Buchse	spacer	4
10	0401008000	Federscheibe	spring washer	8
11	0102008025	Schraube	hex flange bolt	4
12	4540412010	Kappe	spacer	4
13	4540402010	Riemenscheibe	pulley	1
14	4540403010	Messerhalter	adapter	1
15	4540404010/22	Messerhalter	blade	1
16	4540407010/04	Scheibe	spring washer	1
17	4540405010	Messerbolzen	central bolt	1
18	4510201010/01	Vorderachse	front axle weldment	1
19	5310209010	Lager	spherical surface bearing	4
20	5310210010/02	Scheibe	spacer	4
21	5310211010/04	Unterlegscheibe	spring washer	4
22	5310213010	Lager	bearing	10
23	4520204010	Rad	wheel	2
24	0301008000	Unterlegscheibe	flat washer	10
25	0101008015	Bolzen	hex bolt	4
26	4520205010	Rad Abdeckung	hub cap	4
27	4820305010	Rad	rear wheel	2
28	1301009000	Sicherungsring	check ring	2
29	5020311010/04	Friktionsscheibe	mat	4
30	5320326010	Lager	bearing	4
31	5320320010	Zahnrad (links)	left pinion	1
32	5320321010	Zahnrad (rechts)	right pinion	1
33	4520308010	Rad Abdeckung	rear wheel cover	2
34	4520316010/02	Buchse	spacer	2
35	5320324020/02	Lager	left bearing sheath	2
36	5320327010	Staubabdeckung	dustproof ring	2
37	1001020000	Sicherungsring	check ring	2
38	5320328010	nylon Lager	spherical surface bearing	2
39	4520313010/02	Buchse	spacer	1
40	Y054540	Getriebe	gearbox	1
41	4540318010	Rolle	pulley	1
42	5320322010	Stift	pin	2

43	0701005020	Federstift	spring pin	2
44	4520301010/01	Hinterachse	rear axle weldment	1
45	4510303010/80	Höheneinstellungshebel	adjustment lever	1
46	0104006014	Bolzen	cross slot screw	3
47	0202006000	Sicherungsmutter	hex lock nut	9
48	4540102010	Motorabdeckung	motor cover	1
49	0106005019	Schraube	cross slot ST screw	2
50	4540101010	Gehäuse	mower deck	1
51	5320114020/01	Halter	upper bearing bracket	2
52	0102006012	Bolzen	hex flange bolt	8
53	4540103010/22	Halter (links)	left bracket	1
54	4540105010	Unterlegscheibe	spacer of left bracket	2
55	4540107010	Buchse	bush	2
56	4540106010	Scheibe	spacer	4
57	0302010000/02	Scheibe	big washer	5
58	0101010025	Schraube	hex bolt	4
59	0202010000	Sicherungsmutter	hex lock nut	5
60	4820541010/80	Drehgriff (rot)	knob	4
61	4510513010/01	Bolzen	square neck bolt	2
62	4540104010/22	Halter (rechts)	right bracket	1
63	4510107010/01	Höheneinstellung	graduator	1
64	5310317010	Schraubenhalterung	spring bracket	1
65	0102010045	Bolzen	hex flange bolt	1
66	4510113020/22	Klappe	rear cover	1
67	5320127021	Nylon Buchse	bush	2
68	4510114020/02	Stange	pivot of rear cover	1
69	5320136010	Buchse	spacer	2
70	4510115010	Feder	spring of rear cover	1
71	4510111010	Schutz (hinten)	deflector	1
72	4510112010/02	Stange	tail pivot	1
73	4520514010	Buchse	bush	1
74	0102008020	Schraube	hex flange bolt	4
75	0202008000	Sicherungsmutter	hex lock nut	4
76	4540109010	Riemenschutz	belt cover	1
77	0106005019	Schraube	cross slot ST screw	4
78	4520312010	Feder	spring	1
79	4510310020/20	Halterung	linkage	1
80	0301010000	Scheibe	flat washer	2
81	5320333010	Federsplint	check ring	2
82	4510311010/01	Feder	spring	1
83	4520111010	Riemen	belt	1
84	4540503010	Startschalter	switch	1
85	0108005022	Schraube	cross slot ST screw	2
86	4540504010	Griff	drive control lever	1
87	4540501010	Holm (oberer)	upper handle	1

88	4540505010	Kabelschiene	cable bracket	1
89	0106004013	Schraube	cross slot ST screw	4
90	4540507010	Clip	cable clip	3
91	4540502010/22	Griff (unterer)	lower handle	1
92	5310510010/01	Schraube	bolt	2
93	4510510010/01	Scheibe	arc washer	2
94	4540506010	Kupplungszug	clutch cable	1
95	4540506030	Stecker	connector	1
96	4540506040	Kabelschiene	upper cable	1
97	4510602030/22	Gestell (Fangsack)	frame	1
98	4510603030/81	Fangsack	grass bag	1
99	4510602050	Schutz	sheath	2

WB453SE Machine Parts Breakdown CODE:45SE018001S

