



FIG.3 HEAD SUBASSEMBLY, CYLINDER / PLUG,SPARK



Nr.	Ersatzteilnummer	Bezeichnung Englisch	Anzahl
E03-1	12033-Z130110-00A0	GASKET, CYLINDER HEAD COVER BOLT	1
E03-2	12411-Z130110-00A0	COVER, CYLINDER HEAD	1
E03-3	12004-Z130110-00A0	CYLINDER HEAD COVER GASKET	1
E03-4	30010-Z120210-00A0	PLUG, SPARK	1
E03-5	12003-Z080110-00A0	CYLINDER HEAD BOLT	1
E03-6	12140-Z130510-00A0	HEAD SUBASSEMBLY, CYLINDER	1
E03-7	12210-Z130510-00A0	HEAD SUBASSEMBLY, RIGHT CYLINDER	1
E03-8	90502-1220-00A0	POSITION PIN	1
E03-9	12131-Z130120-00A0	GASKET, CYLINDER HEAD	1
E03-10	12134-Z130110-00A0	CORE VENEER	1
E03-11	90204-0845-A1A0	STUD BOLT	1
E03-12	90203-Z010110-00A0	STUD BOLT	1
E03-13	12411-Z130210-00A0	COVER, CYLINDER HEAD	1
E03-14	15031-Z120110-Q5A0	PLUG, ENGINE OIL	1
E03-15	90681-Z080210-00A0	RING, SEAL	1
E03-16	12031-Z130110-00A0	CYLINDER HEAD BOLT WASHER	1


E03-17	12032-Z130210-00A0	CYLINDER HEAD COVER BOLT	1
E03-18	90007-0816-A1A0	BOLT	1
E03-20	12008-Z130110-00A0	LUG	1
E03-21	90013-Z130210-00A0	BOLT, HEXAGONAL FLANGE SHOULDER	1

FIG.4 ROD,CRANKSHAFT CONNETING




Nr.	Ersatzteilnummer	Bezeichnung Englisch	Anzahl
E04-1	13300-Z121010-0000	CRANKSHAFT ASSY.	1
E04-2	13306-Z130110-00A0	WASHER, THRUST	1
E04-3	13010-Z130210-00A0	ROD, CONNECTING	1
E04-4	13111-Z120110-00A0	PISTON	1
E04-5	13121-Z130110-00A0	PIN, PISTON	1
E04-6	13122-Z130110-00A0	CLIP, PISTON PIN	1
E04-7	13200-Z120110-00A0	RING ASSY, PISTON	1

FIG.5 TRAIN,VALVE / CAMSHAFT SUBASSEMBLY



Nr.	Ersatzteilnummer	Bezeichnung Englisch	Anzahl
E06-1	14310-Z130210-00A0	ROCKER SUBASSEMBLY, VALVE	1
E06-2	14330-Z130310-00A0	SHAFT, VALVE ROCKER	1
E06-3	14070-Z130210-00A0	LIFTER SUBASSEMBLY, VALVE	1
E06-4	14081-Z130110-00A0	TAPPET, VALVE	1
E06-5	12109-Z400110-00A0	CLAMP, VALVE LOCK	1
E06-6	12112-Z400110-00A0	SEAT, VALVE SPRING	1
E06-7	12103-Z130110-00A0	SPRING, VALVE	1
E06-8	12101-Z080110-00A0	GUIDE, SEAL	1
E06-9	12105-Z130110-00A0	RETAINER, VALVE SPRING	1
E06-10	12110-Z130310-00A9	VALVES SET	1
E06-11	14200-Z130210-00A0	CAMSHAFT ASSY.	1
E06-12	14215-Z130110-00A0	WASHER, CAMSHAFT	1
E06-13	14312-Z240110-00A0	NUT, VALVE LOCK	1


FIG.6 OUTER HOUSING



FR. 

Nr.	Ersatzteilnummer	Bezeichnung Englisch	Anzahl
E07-1	30028-Z130110-Q2A0	SHIELD, SHROUD	1
E07-2	90103-0508-A1A0	CROSS-RECESSED PAN HEAD SCREW	1
E07-3	90314-Z130210-00A0	NUT	1
E07-4	19330-Z130110-Q2A0	SHROUD ASSY.	1
E07-5	19303HZ130110-Q2A0	PLATE, FAN SHIELD DECORATED	1
E07-6	24540-Z130110-00A0	HANDLE SUBASSEMBLY, LOCK	1


FIG.7 SHROUD / SHIELD,LOWER



Nr.	Ersatzteilnummer	Bezeichnung Englisch	Anzahl
E08-1	19305-Z130110-00A0	SHROUD 2, CYLINDER BODY	1
E08-2	30003-Z130110-00A0	CONDUCTOR, UNILATERALISM	1
E08-3	19304-Z130110-00A0	SHROUD, CYLINDER BODY	1
E08-4	19340HZ120110-01A0	SHIELD,LOWER	1
E08-5	90001-0610-01A0	HEXAGON SOCKET FLANGE FACE BOLT - SMALL SERIES	1
E08-6	19308-Z130120-00A0	BODY LEFT SHIELD	1
E08-7	90013-Z130210-00A0	BOLT, HEXAGONAL FLANGE SHOULDER	1
E08-8	12008-Z130110-00A0	LUG	1
E08-9	90013-Z130210-00A0	BOLT, HEXAGONAL FLANGE SHOULDER	1
E08-10	19307HZ120110-0000	LOWER RIGHT SHIELD	1
E08-11	90722-Z120110-00A0	PLUG, END	1
E08-12	19309-Z130130-00A0	BODY RIGHT SHIELD	1
E08-13	90692-Z120410-00A0	O-TYPE RUBBER SEAL RING	1
E08-14	15229-Z120150-00A0	OIL FILTER HOLDER	1
E08-15	15208-Z120130-00A0	TUBE, OIL FILTER INSTALLATION	1


E08-16	15220-Z120210-00A0	FILTER SUBASSEMBLY, OIL	1
E08-17	90408-Z010110-00A0	FLAT WASHER	1
E08-18	19112-Z120120-00A0	ADAPTER, COOLING PIPE	1
E08-19	19100-Z120110-00A0	RADIATOR ASSY.	1
E08-20	90007-0620-A1A0	HEXAGON SOCKET FLANGE FACE BOLT - SMALL SERIES	1
E08-21	90685-D180-0EA0	PIPE CLAMP	1
E08-22	19111-Z120130-00A0	PIPE, COOLING	1
E08-23	19111-Z120230-00A0	PIPE, COOLING	1
E08-24	30052-Z120110-00A0		1
E08-25	30060-Z120120-00A0	REGULATOR, VOLTAGE	1
E08-26	90681-Z090110-00A0	RING, SEAL	1
E08-27	90684-Z030120-00A0	WIRE CLIP	1

FIG.8 CARBURETOR ASSY.




Nr.	Ersatzteilnummer	Bezeichnung Englisch	Anzahl
E09-1	16001-Z130110-00A0	CARBURETOR SEAL GASKET	1
E09-2	16002-Z130120-00A0	GASKET, CARBURETOR INSULATOR	1
E09-3	12501-Z120120-00A0	JOINT, INTAKE TUBE	1
E09-4	90007-0630-A1A0	HEXAGON SOCKET FLANGE FACE BOLT - BIG SERIES - GRADE B	1
E09-5	90007-0665-A1A0	HEXAGON SOCKET FLANGE FACE BOLT - BIG SERIES - GRADE B	1
E09-6	90692-Z120310-00A0	O-TYPE RUBBER SEAL RING	1
E09-7	17112HZ120130-00A1	#NV	1
E09-8	90001-0695-01A0	HEXAGON SOCKET FLANGE FACE BOLT - SMALL SERIES	1
E09-9	16100-Z120210-00AA	CARBURETOR ASSY.	1
E09-10	35665-Z120120-00A0	LINE, SOLENOID VALVE AC	1
E09-11	90686-Z030310-00M0	TUBE, FUEL	1
E09-12	16001-Z130210-00A0	CARBURETOR SEAL GASKET	1

FIG.9 FLYWHEEL / IMPELLER / STARTER PULLEY / IGNITION COIL




Nr.	Ersatzteilnummer	Bezeichnung Englisch	Anzahl
E10-1	30400-Z130510-00A0	COIL, IGNITION	1
E10-2	30400-Z130610-00A0	COIL, IGNITION	1
E10-3	90007-0630-A1A0	HEXAGON SOCKET FLANGE FACE BOLT - BIG SERIES - GRADE B	1
E10-4	28001-Z130110-00A0	DOUBLE HEAD SUPPORT BOLT	1
E10-5	28001-Z130210-00A0	DOUBLE HEAD SUPPORT BOLT	1
E10-6	30140-Z120110-00A0	COIL SUBASSEMBLY, CHARGE	1
E10-7	90007-0635-A1A0	BOLT	1
E10-8	13500-Z120120-00A0	FLYWHEEL ASSY.	1
E10-9	90407-Z130120-00A0	WASHER, FLAT	1
E10-10	13502-Z130110-00A0	BOLT, FLYWHEEL	1
E10-11	19352-Z130110-00A0	IMPELLER	1
E10-12	13515-Z130110-00A0	TRAY, IMPELLER SETTING	1
E10-13	90001-0816-01A0	HEXAGON SOCKET FLANGE FACE BOLT - SMALL SERIES	1
E10-14	90502-1014-00A0	POSITION PIN - TYPE A	1
E10-15	30300-Z130121-00A0	STARTING MOTOR ASSEMBLY	1
E10-16	90001-08B0-01A0	HEXAGON SOCKET FLANGE FACE BOLT - SMALL SERIES	1
E10-17	37050-Z130110-00A0	PROTECTOR, OIL	1
E10-18	90001-0610-01A0	BOLT	1

FIG.10 CONTROL ASSY, THROTTLE




Nr.	Ersatzteilnummer	Bezeichnung Englisch	Anzahl
E11-1	16520-Z130120-00A0	CONTROL ASSY, THROTTLE	1
E11-2	90007-0616-A1A0	BOLT	1
E11-3	16063-Z130210-00A0	SPRING, GOVERNOR	1
E11-4	16236-Z130210-00A0	SPRING, CHOKE RETURN	1
E11-5	16063-Z130420-00A0	SPRING, GOVERNOR	1
E11-6	90305-0600-31A0	HEXAGON NUT WITH FLANGE	1
E11-7	16072-Z010110-00A0	BOLT, GOVERNOR SUPPORT	1
E11-8	16071-Z130110-00A0	GOVERNOR BRACKET	1
E11-9	16062-Z120110-00A0	ROD, GOVERNEOR	1
E11-10	16012-Z120210-00A0	SPRING, THROTTLE VALVE RETURNING	1
E11-11	16123-Z120120-00A0	CHOKE PULL ROD	1
E11-12	16011-Z130120-00A0	CLIP, CHOKE ROD	1
E11-13	16040-Z120110-00A0	CABLE ASSY, THROTTLE	1

FIG.11 CLEANER, AIR



Nr.	Ersatzteilnummer	Bezeichnung Englisch	Anzahl
F01-1	17100-Z120110-00A0	AIR CLEANER	1
F01-8	12503-Z120110-00A0	COVER, INTAKE TUBE	1
F01-9	90007-0630-A1A0	BOLT	1
F01-10	90107-4225-51A0	CROSS-RECESSED PAN HEAD SELF-TAPPING SCREW	1
F01-11	90740-Z130120-00A0	COLLAR	1
F01-13	12503-Z120210-00A0	COVER, INTAKE TUBE	1

FIG.12 MUFFLER ASSY.



Nr.	Ersatzteilnummer	Bezeichnung Englisch	Anzahl
F02-1	18100-Z120410-0000	MUFFLER ASSY.	1
F02-2	18001-Z190110-00A0	GASKET, EXHAUST OUTLET	1
F02-3	90001-0816-01A0	BOLT	1
F02-4	90314-Z130120-00A0	NUT	1
F02-6	30360-Z120110-00A1	SUPPORT SUBASSEMBLY, CONTROL BOX	1
F02-7	30350-Z120320-00A0	STARTING CONTROL BOX	1
F02-8	90007-0612-A1A0	BOLT	1