



Model:LC1P75F
Status Code:L3372
Air Cleaner




7			
Air Cleaner Spare Parts			
REF.	PART NUMBER	Name_English	QTY.
1	180020744-0002	Air filter	1
2	181950006-0001	Bolt handle	1
3	180070228-0001	Air filter casing cover	1
4	180100096-0002	Air filter element combination	1
5	180280029-0001	Air filter seat	1
6	380741886-0001	Breather tube	1
7	380370066-0001	Hexagon nut with flange	2

Model:LC1P75F
Status Code:L3372
Carburetor




6 Carburetor Spare Parts			
REF.	PART NUMBER	Name_English	QTY.
1	170430174-0001	Carburetor gasket	1
2	170440090-0001	Heat insulating pad for carburetor	1
3	170430147-0001	Carburetor gasket	2
4	170450007-0001	Heat insulating plate for carburetor	1
5	380180093-0001	Stud	2
6	170022142-0002	Carburetor	1
7	170430177-0001	Carburetor gasket	1

Model:LC1P75F
Status Code:L3372
Control System




8	Control System Spare Parts		
REF.	PART NUMBER	Name_English	QTY.
1	171590068-0001	Throttle rod	1
2	171610031-0001	throttle return spring	1
3	171620016-0003	Speed regulating bracket	1
4	171600080-0001	Governing spring	1
5	171680146-0001	Throttle handle combination	1
6	380850048-0001	Stay stud	1
7	171740011-0001	Guard plate for throttle combination	1
8	380020070-0001	Hexagon shaft shoulder bolt	2
9	380140013-0005	Hexagon bolt with flange	1
10	381350004-0001	Pin clip	1
11	380650338-0001	Oil seal	1
12	380450527-0001	Flat washer	1
13	171630042-0001	Speed regulating arm	1

Model:LC1P75F
Status Code:L3372
Crank Case Cover




3	Crank Case Cover Spare Parts		
REF.	PART NUMBER	Name_English	QTY.
1	380600120-0001	ocation pin	2
2	110820429-0001	Crankcase cover	1
3	150350037-0001	Oil filter	1
4	150840002-0002	Oil filter Mounting bolts	1
5	380650347-0001	Oil seal	1
6	380140067-0003	Hexagon bolt with flange	1
7	150340029-0001	Cover,Oil Strainer	1
8	150290028-0001	Engine oil Strainer	1
9	380451035-0001	Flat washer	1
10	381350020-0001	Pin clip	1
11	196150005-0001	worm gear	1
12	380451036-0001	Flat washer	1
13	193050027-0001	Output shaft	1
14	380650666-0001	Oil seal	1
15	380450514-0001	Flat washer	1
16	292980356-0001	tube comp.	1
17	150010182-0001	Components of oil pump	1
18	380140005-0006	Hexagon bolt with flange	8
19	380841739-0001	Seal ring	1
20	150040097-0001	Oil pump cover	1
21	380140013-0005	Hexagon bolt with flange	3
22	380140077-0005	Hexagon bolt with flange	1
23	174280009-0001	Components of governor gear	1
24	380600121-0001	ocation pin	2

Model:LC1P75F
Status Code:L3372
Crank Case




2		Crank Case Spare Parts	
REF.	PART NUMBER	Name_English	QTY.
1	110810612-0001	Crankcase body	1
2	380650335-0001	Oil seal	1
3	293030019-0001	Engine brake	1
4	380140077-0005	Hexagon bolt with flange	1
5	381140580-0001	Tension spring	1
6	380822372-0001	Bushing	1
7	110690162-0001	Oil rule combination	1
8	380140100-0003	Hexagon bolt with flange	1
9	160200068-0002	Side plate	1
10	380140067-0003	Hexagon bolt with flange	2
11	110840041-0001	CAP,BREATHER CHAMBER	1
12	110850030-0002	PACKING, BREATHER CHAMBER	1
13	380140039-0003	Hexagon bolt with flange	1
14	140250032-0001	Leaf valve	1
15	380821590-0001	Bushing	2

Model:LC1P75F
Status Code:L3372
Crankshaft



4	Crankshaft Spare Parts		
REF.	PART NUMBER	Name_English	QTY.
1	130070158-0001	Piston ring combination	1
2	130030245-0001	Piston	1
3	130060031-0001	Piston pin	1
4	380560056-0001	Steel cable baffle ring	2
5	130150181-0001	Connecting rod	1
6	130180030-0001	Connecting rod bolt	2
7	140020366-0001	Camshaft assy	1
8	130290905-0001	crankshaft	1
9	380630137-0002	Bearing	1
10	380450518-0001	Flat washer	1
11	380630026-0001	Bearing	2
12	130450105-0001	Balancing shaft	1
13	130450109-0001	Balancing shaft	1
14	380450560-0001	Flat washer	1
15	380451734-0001	Flat washer	1

Model:LC1P75F
Status Code:L3372
Cylinder Head



1	Cylinder Head Spare Parts		
REF.	PART NUMBER	Name_English	QTY.
1	380140013-0005	Hexagon bolt with flange	1
2	120230152-0001	Cylinder head cover	1
3	120250059-0001	Gasket for cylinder head cover	1
4	140450022-0001	Valve rocker combination	2
5	140710015-0001	Plate, push rod guide	1
6	140380020-0001	Retainer, valve spring	2
7	140340039-0001	Inner spring of valve	2
8	500550076-0001	Valve Kit	1
9	140670032-0001	Push rod	2
10	140690002-0001	Lifter, Valve	2
11	270960046-0001	Spark plug	1
12	380140339-0001	Hexagon bolt with flange	7
13	140400016-0001	Valve oil seal	1
14	120080609-0002	Cylinder head	1
15	120150211-0002	Gasket for cylinder head	1
16	380600117-0001	ocation pin	2
17	380180114-0001	Stud	2
18	270920696-0001	COIL ASSY.,IGNNTION	1
19	380140103-0004	Hexagon bolt with flange	1

Model:LC1P75F
Status Code:L3372
Decals

1



2



3



4



5



6




7



11	Decals Spare Parts		
REF.	PART NUMBER	Name_English	QTY.
1	370320219-0001	Reminder decal	1
2	370320347-0001	Reminder decal	1
3	370324988-0001	Reminder decal	1
4	EL-XCV300-1	Reminder decal	1
5	EL-V225-1	Reminder decal	1
6	370329891-0001	Reminder decal	1
7	370340627-0001	Certification decal	1


10	Fuel Tank Spare Parts		
REF.	PART NUMBER	Name_English	QTY.
1	380900062-0001	Strap	2
2	170490495-0001	Tank	1
3	170870228-0001	Tank cover	1
4	380750558-0001	Oil tube	1
5	380960120-0004	Clip combination	2
6	170010069-0001	Fuel filter	1
7	380930092-0001	Location wire nail	1
8	380140013-0005	Hexagon bolt with flange	5
9	170650092-0001	Tank bracket	1

Model:LC1P75F
Status Code:L3372
Muffler



9 Muffler Spare Parts			
REF.	PART NUMBER	Name_English	QTY.
1	173090001-0001	Locker of choke valve pull rob	1
2	171650034-0001	Choke valve pull rod	1
3	380370048-0001	Hexagon nut with flange	2
4	180572898-0001	Muffler	1
5	180660114-0001	Muffler gasket	1

Model:LC1P75F
Status Code:L3372
Stator Subassembly



5 Starter Subassembly Spare Parts			
REF.	PART NUMBER	Name_English	QTY.
1	270020254-0001	FLYWHEEL COMP	1
2	193590057-0001	Starting disc	1
3	380370051-0001	Hexagon nut with flange	1
4	380850047-0001	Stay stud	2
5	380850002-0001	Stay stud	1
6	160210304-0001	Fan cover comp.	1
7	193500248-0001	Manual starting components	1
8	380330056-0001	Cap nut	3